

# WeChat RFID13.56MHZ WG



## MQ-360R

名稱:	WeChat   RFID13.56MHZ WG  
型號:	MQ-360R
電壓:	DC 12V
通訊協議:	支援 WeChat 通訊
QR 碼類型:	COMS
QR 碼數量:	> 80 個
QR 碼讀取時間:	<0.01s
RFID 類型:	IC (13.56MHZ)
通訊距離:	3 ~ 10CM
尺寸:	114 * 74 * 21 (mm)
重量:	0.15KG

OEM:

□□□

□□□□ □□ □□ MQ-360R □□□□

## Size



## Appearance



# RFID Card & WeChat Mini Program Open door



QR code display window  
Long press to send (call WeChat)  
Users can also send screenshots to guests.

有效期/次:2018-02-27 22:46/不限

QR code validity period and frequency hint



Set the effective time and number of QR codes  
(1 minute to 24 hours, default 10 minutes unlimited)

Set the effective times of QR codes  
(1~9 times, 0 is unlimited, default is not limited)

Click to regenerate the QR code as above setting


Click to display the user ID number

After the user's mobile phone WeChat added "QROPEN" applet, click "Register" to display the user card number (8-digit decimal) generated by the applet by default. The card number is fixed for a long time.


Each time the user uses it, just click "Open Code" to display a 10-minute valid QR code. Then, after brushing the code on the access control, the access control will identify the user's card number, timeout or super time. After that, the access control will not be accepted. The user applet card number is fixed and will not change with the change of the QR code.

When a guest visits, the user opens the "open code" and sets the effective time and number of the QR code. Click "Generate QR Code" to refresh a QR code immediately. The QR code does not need to be authorized again! After the user takes a screen shot, they use the online chat software such as WeChat to send the guest, and the guest can open the door within the set time and number of times.

# Wire diagram



# Applicable place



Access controller



Barrier gate

□□□□ □□□□ □□ □□□□

