


□□□□□□□□□□□□□□□□



# Emergency call button



## EB-128L□□□□□

□□□□	□□□□□□□□□□□□□□□□
□□□	EB-128L
□□□□□	1.25□
□□□□□	□□12V
□□□□□	≤95□
□□□	> 10000□
□□□□□	□□□□
□□□	86□□×86□□×10□□
□□□	□□□□□□□□
□□□□	□□□□□□□□□□□□□□□□
□□□	PC + PCB□
□□□	100□
□□□	□□□□ 1□/□

□□□□□□□□	-20°C□70°C
□□□	1□□□
OEM□	□□OEM

EB-128L□□□□□□

## Size



# Apperance



# Specification



2 ways triggered



